

Closed - Tray Technique



STEP 1: Use appropriate instrument to remove healing abutment. Start with posterior implant, working forward. Remove one healing abutment



STEP 2: Place the impression post (impression coping) onto the implant, ensure the two pieces are fully engaged and hand tighten the screw.



STEP 3: Take a PA to verify all parts are seated. When working with multiple implants, place all impression posts in one arch before taking PA.



STEP 4: Inject your preferred PVS syringe material around each impression post, fill the tray with heavy body and record impression.



STEP 5: Using the recommended instrument, remove the impression posts from the patient's mouth and replace the healing abutment.



STEP 6: Place the impression posts into the corresponding location in the impression and send the case to Mabel Dental Lab.